



1 April 2008

Schedule of Loss Factors

To facilitate the allocation and reconciliation of Grid Exit Point electricity volumes, the following loss factors should be used for electricity traded across the Network Waitaki Ltd network.

Code	Description	Anytime Loss Factor
WLV	Installations metered at low voltage	1.060
W11	Installations metered at 11kV	1.025
W110	Installations metered at 110kV	1.000

These factors have been based on the historical, long run, loss trends and include both technical and non-technical losses.

Derek Atkinson
Network Operations Manager